

Issue date: 2020-02-28

Question: Shutdown of FlexStand takes a long time

Applies to: All FlexStand OI versions

Answer: You may experience a slow shutdown of FlexStand after having used the LabVIEW adaptor.

This is a known problem and NI has listed this as a known issue with ID 632567.

However, there is a workaround for this issue. In the Adapters.cfg file located in C:\ProgramData\National Instruments\TestStand <version>\Cfg, set the _FlexGAdp_WaitForLVRTECleanupAtShutdown key to False. The delay will be significantly reduced after this key has been changed.